

To Determine Void: Enter graph at [Point A] Pole Dia line (using the appropriate pole diameter) and trace down line to the intersection with vertical line representing difference between pole and hole diameters [Point B]. Follow left parallel to horizontal lines to Cu.Ft. per foot of depth [Point C]. Multiply this number by the depth of the hole (in feet) and you have determined the total void you need to fill.

